




## **Front View**




## **Rear View**



## **RMS-1T-LP**





## Electrical Box #6-32 Screws (2)

To Close Station:
If hex Screw Model, simply push station closed.
If Key Lock Model, hold station closed then turn key counterclockwise.

RMS-1T Installation Manual GLT-360-7-1 (001)